

2019

BENT TREE ASSOCIATION  
BENT TREE SWIMMING POOL  
MAIN POOL WATER LEVEL

Attend to the main pool water level as follows:

Definitions:

Low Level

Low Water Level is within 1" of the bottom of the surface skimmer

High Level

High Water Level is at the center of the surface skimmer opening

Instructions:

1. Add water when water reaches the Low Level.
2. Shut off water when level reaches the High Level.

Procedure:

To add water

1. Open the Main Pool "BALL" Fill Valve

To shut off water:

1. Close the Main Pool "Ball" Fill Valve.
2. NOTE: If instructed by the Pool Manager, also close the Main Pool "Globe" Fill Valve.