

**BENT TREE ASSOCIATION
2019
BENT TREE SWIMMING POOL**

POOL CLEANER (SPARKY) OPERATION

THE POOL CLEANER SYSTEM IS MOUNTED ON A CADDY CART AND CONTAINS THE CLEANER, TETHER CORD, and POWER PACK.

The AC extension cord reel should be used ONLY for SPARKY

TO OPERATE CLEANER:

- 1. Locate the Cart at the Shallow end of the pool.**
- 2. Locate the AC Power Cord Reel near the Cart.**
- 3. Pull to unreel the desired amount of AC cord to reach and plug into either GFI outlet on the pool house.**
- 4. Plug in the power pack to the AC Power Cord Reel Outlet**
- 5. Gently place Sparky into the shallow end of the pool. Rock Sparky side to side to allow all air to escape for the housing.**
- 6. Unreel the tether cord into the pool.**
- 7. Remove any kinks in the tether cord so that the cord floats freely on the pool surface. (It may be necessary to lay out and unkink the cord on the deck)**
- 8. Wrap tether cord around ladder to the red marker**
- 9. Connect the tether cord to the Power-Pack. CAREFULLY align the receptacle slot with the Plug "key". Insert the plug and loosely tighten the nut.**
- 10. Turn on the Power-Pack. Check to see if Sparky is operating.**

TO REMOVE AND STORE CLEANER:

- 1. Turn off Power-Pack.**
- 2. Unplug power cord and disconnect the tether cord from the Power-Pack.**
- 3. Untangle cord. (It may be necessary to lay out and unkink the cord on the deck)**
- 4. Gently pull Sparky to the side of the pool (With tether cord).**
- 5. Gently pull Sparky out of the pool - Use Handle**
- 6. Gently place Sparky onto the cart.**
- 7. CHANGE THE HANDLE POSITION. See Dolphin Operating Instructions.**
- 8. Reel in the AC power cord.**
- 9. Loosely coil up the tether cord on the cart using cross-loop method. (DO NOT WIND TIGHTLY)**
- 10. Remove dirt bag from cleaner housing**
- 11. Clean (hose out) housing and dirt bag.**
- 12. Replace dirt bag (use other clean and dry bag) Stow Sparky Hand Truck in shed.**