

**BENT TREE ASSOCIATION
BENT TREE SWIMMING POOL
2019**

TO: ALL LIFEGUARDS

SUBJECT: MAIN POOL HEATER OPERATION

TO TURN HEATER ON:

- 1. Locate the three (3) valves above the main filters**
- 2. Open Feed to the heater fully, and the Return Valve from the heater approximately $\frac{1}{2}$.**
- 3. Close off the by-pass valve until the heater flow meter reads approx. 50 GPM**
- 4. Turn on heater switch (Located on conduit box on side of heater. Use stick to operate toggle switch from outside the pen fence.**

TO TURN HEATER OFF:

- 1. Turn off heater switch (Located on conduit box on side of heater. Use stick to operate toggle switch from outside the pen fence.**
- 2. Open the By- Pass valve fully, and close the “TO” and “FROM” valves fully.**